

RENWIL®
EST. 1967



FENICE
LPC4515

c UL us LISTED

RENWIL®
EST. 1967



x1 Ⓐ | x1 Ⓑ | x2 Ⓒ | x2 Ⓓ | x3 Ⓔ

-- Risk of fire: use max 60w incandescent type A bulb or 9w sbled 120v 60Hz AC only.
-- Risque d'incendie: utilisé une ampoule type A 60w incandescence max ou 9w sbled 120v 60Hz C.A seulement.

ENGLISH

-- Bulb not included.
To reduce the risk of fire, electric shock or personal injury:
-- A licensed electrician is required for installation;
-- Turn off / unplug the light fixture and allow the bulb to cool before replacement;
-- Do not look directly at lighted bulb;
-- Keep materials that burn easily away from lighted bulb;
-- Never exceed maximum wattage indicated as it may cause fire;
-- For maintenance, use soft cloth to dust and clean the light fixture. Do not use surface cleaners that could damage the finish.

FRANÇAIS

-- Ampoule non incluse.
Pour réduire les risques d'incendie, de choc électrique ou de blessure:
-- Un électricien agréé est requis pour l'installation;
-- Éteindre / débrancher le luminaire et laisser l'ampoule refroidir avant de la remplacer;
-- Ne regarder pas directement l'ampoule allumée;
-- Garder les matériaux inflammables à l'écart des ampoules allumées;
-- Ne dépassez jamais la puissance maximale indiquée, car cela pourrait provoquer un incendie;
-- Pour l'entretien, utilisez un chiffon doux pour dépoussiérer et nettoyer le luminaire. N'utilisez pas de nettoyants pour surfaces qui pourraien endommager la finition..

RENWIL®
EST. 1967

