


RENWIL®

EST. 1967



- Risk of fire: Use max 9W LED type A bulb with E26 base. 120V ~ 60Hz AC only.
- Risque d'incendie: Utiliser une ampoule DEL type A de 9W avec culot E26, 120 V ~ 60 Hz CA seulement.



ENGLISH

- LED bulb not included.

To reduce the risk of fire, electric shock or personal injury:

- A licensed electrician is required for installation;
- Turn off / unplug the light fixture and allow the bulb to cool before replacement;
- Do not look directly at lighted bulb;
- Keep materials that burn easily away from lighted bulb;
- Use an LED bulb only;
- Never exceed maximum wattage indicated as it may cause fire;
- For maintenance, use soft cloth to dust and clean the light fixture. Do not use surface cleaners that could damage the finish.

FRANÇAIS

- Ampoule DEL non incluse.

Pour réduire les risques d'incendie, de choc électrique ou de blessure:

- Un électricien agréé est requis pour l'installation;
- Éteindre / débrancher le luminaire et laisser l'ampoule refroidir avant de la remplacer;
- Ne regarder pas directement l'ampoule allumée;
- Garder les matériaux inflammables à l'écart des ampoules allumées;
- Utiliser une ampoule DEL seulement;
- Ne dépassez jamais la puissance maximale indiquée, car cela pourrait provoquer un incendie ;
- Pour l'entretien, utilisez un chiffon doux pour dépoussiérer et nettoyer le luminaire. N'utilisez pas de produits nettoyants pour surfaces qui pourraient endommager la finition.

RENWIL®

EST. 1967

