

EVERREN



NOTTINGHAM
LPF3174

c UL us LISTED

EVERREN



-- Risk of fire: Use max 60W incandescent type A bulb with E26 base, or 9W LED type A bulb with E26 base. 120V ~ 60Hz AC only.
-- Risque d'incendie: Utiliser une ampoule type A de 60W max. avec culot E26, ou une ampoule DEL type A de 9W avec culot E26. 120V ~ 60 Hz CA seulement.

ENGLISH

-- Plastic Covers (B4) are just packaging material for cord protection, please do remember to remove them before assembly.
-- Bulb not included,
-- Do not operate the foot switch with wet feet or while standing in water to avoid risk of electric shock.
To reduce the risk of fire, electric shock or personal injury:
-- Turn off / unplug the light fixture and allow the bulb to cool before replacement;
-- Do not look directly at lighted bulb;
-- Keep materials that burn easily away from lighted bulb;
-- Never exceed maximum wattage indicated as it may cause fire;
-- For maintenance, use soft cloth to dust and clean the light fixture. Do not use surface cleaners that could damage the finish.

FRANÇAIS

-- La gaine de protection en plastique (B4) n'est qu'un matériau d'emballage utilisé pour la protection des cordons électriques.
-- Ampoule non incluse,
-- Ne pas utiliser l'interrupteur au pied avec les pieds mouillés ou en étant debout dans l' eau afin d'éviter tout risque de choc électrique.
Pour réduire les risques d'incendie, de choc électrique ou de blessure:
-- Éteindre / débrancher le luminaire et laisser l'ampoule refroidir avant de la remplacer;
-- Ne regarder pas directement l'ampoule allumée;
-- Garder les matériaux inflammables à l'écart des ampoules allumées;
-- Ne dépassez jamais la puissance maximale indiquée, car cela pourrait provoquer un incendie ;
-- Pour l'entretien, utilisez un chiffon doux pour dépoussiérer et nettoyer le luminaire. N'utilisez pas de nettoyants pour surfaces qui pourraien endommager la finition.

EVERREN

