

EVERREN



LUXOR
LPT1417EV

EVERREN



-- Risk of fire: Use max 150W incandescent type A 3-way bulb with E26 base, or 25W LED type A 3-way bulb with E26 base.120V ~ 60Hz AC only.
-- Risque d'incendie: Utiliser une ampoule incandescente 3-voies type A de 150W max. avec culot E26, ou une ampoule 3-voies DEL type A de 25W avec culot E26. 120 V ~ 60 Hz CA seulement.

ENGLISH

-- Bulb not included,Use a 3-way light bulb to obtain three levels of brightness. When using a standard bulb, the lamp will function only as ON/OFF.
To reduce the risk of fire, electric shock or personal injury:
-- Turn off / unplug the light fixture and allow the bulb to cool before replacement;
-- Do not look directly at lighted bulb;
-- Keep materials that burn easily away from lighted bulb;
-- Never exceed maximum wattage indicated as it may cause fire;
-- For maintenance, use soft cloth to dust and clean the light fixture. Do not use surface cleaners that could damage the finish.

FRANÇAIS

-- Ampoul non incluse,Pour obtenir trois niveaux de luminosité, utilisez une ampoule à 3 intensités. Avec une ampoule standard, la lampe fonctionne uniquement en marche/arrêt.
Pour réduire les risques d'incendie, de choc électrique ou de blessure:
-- Éteindre / débrancher le luminaire et laisser l'ampoule refroidir avant de la remplacer;
-- Ne regarder pas directement l'ampoule allumée;
-- Garder les matériaux inflammables à l'écart des ampoules allumées;
-- Ne dépassez jamais la puissance maximale indiquée, car cela pourrait provoquer un incendie;
-- Pour l'entretien, utilisez un chiffon doux pour dépoussiérer et nettoyer le luminaire. N'utilisez pas de nettoyants pour surfaces qui pourraien endommager la finition.

EVERREN

