



EVERREN



EVERREN



- Risk of fire: Use max 150W incandescent type A 3-way bulb with E26 base, or 25W LED type A 3-way bulb with E26 base. 120V ~ 60Hz AC only.
- Risque d'incendie: Utiliser une ampoule incandescente 3-voies type A de 150W max. avec culot E26, ou une ampoule 3-voies DEL type A de 25W avec culot E26. 120 V ~ 60 Hz CA seulement.



ENGLISH

- Bulb not included, Use a 3-way light bulb to obtain three levels of brightness. When using a standard bulb, the lamp will function only as ON/OFF.
- To reduce the risk of fire, electric shock or personal injury:
- Turn off / unplug the light fixture and allow the bulb to cool before replacement;
- Do not look directly at lighted bulb;
- Keep materials that burn easily away from lighted bulb;
- Never exceed maximum wattage indicated as it may cause fire;
- For maintenance, use soft cloth to dust and clean the light fixture. Do not use surface cleaners that could damage the finish.

FRANÇAIS

- Ampoule non incluse. Utilisez une ampoule à trois intensités pour bénéficier de trois niveaux de luminosité. Si vous utilisez une ampoule standard, la lampe ne fonctionnera qu'en mode allumé/éteint.
- Pour réduire les risques d'incendie, d'électrocution ou de blessures :
- Éteignez et débranchez la lampe, puis laissez l'ampoule refroidir avant de la remplacer ;
- Ne regardez pas directement l'ampoule allumée ;
- Éloignez les matériaux inflammables de l'ampoule allumée ;
- Ne dépassez jamais la puissance maximale indiquée, car cela pourrait provoquer un incendie ;
- Pour l'entretien, utilisez un chiffon doux pour dépoussiérer et nettoyer le luminaire. N'utilisez pas de produits nettoyants qui pourraient endommager la finition.

EVERREN

