



EVERREN



EVERREN



- Risk of fire: Use max 100W incandescent type A 3-way bulb with E26 base, or 15W LED type A 3-way bulb with E26 base. 120V ~ 60Hz AC only.
- Risque d'incendie: Utiliser une ampoule incandescente 3-voies type A de 100W max. avec culot E26, ou une ampoule 3-voies DEL type A de 15W avec culot E26. 120 V ~ 60 Hz CA seulement.



ENGLISH

- Bulb not included. Use a 3-way light bulb to obtain three levels of brightness. When using a standard bulb, the lamp will function only as ON/OFF.

To reduce the risk of fire, electric shock or personal injury:

- Turn off / unplug the light fixture and allow the bulb to cool before replacement;
- Do not look directly at lighted bulb;
- Keep materials that burn easily away from lighted bulb;
- Never exceed maximum wattage indicated as it may cause fire;
- For maintenance, use soft cloth to dust and clean the light fixture. Do not use surface cleaners that could damage the finish.

FRANÇAIS

- Ampoule non incluse. Pour obtenir trois niveaux de luminosité, utilisez une ampoule à 3 intensités. Avec une ampoule standard, la lampe fonctionne uniquement en marche/arrêt.

Pour réduire les risques d'incendie, de choc électrique ou de blessure:

- Éteignez / débranchez le luminaire et laissez l'ampoule refroidir avant de la remplacer;
- Ne regarder pas directement l'ampoule allumée;
- Garder les matériaux inflammables à l'écart des ampoules allumées;
- Ne dépassez jamais la puissance maximale indiquée, car cela pourrait provoquer un incendie ;
- Pour l'entretien, utilisez un chiffon doux pour dépolssiérer et nettoyer le luminaire. N'utilisez pas de nettoyeurs pour surfaces qui pourraient endommager la finition.

EVERREN

