


2. Quick taps to:

- turn on
- turn off the lamp

Appuyez rapidement pour :

- allumer
- éteindre la lampe



To dim, turn on the lamp, then press and hold the power button.



When the desired setting is reached, release the power button.

When the lamp is turned on and off, it will return to the same brightness level it had when it was last turned off.

Pour diminuer l'intensité, allumez la lampe, puis appuyez et maintenez le bouton d'alimentation.


Lorsque le réglage souhaité est atteint, relâchez le bouton d'alimentation.

Lorsque la lampe est éteinte et rallumée, la luminosité reviendra au même niveau qu'elle avait lors du dernier arrêt.



# RENWIL®

EST. 1967



X1

(A)




X1

(B)



X1

(C)



X1

(D)



ENGLISH

LED table lamp with dimmable touch switch.  
Indoors only.

Instructions for use:  
Follow step 1 and 2

- This rechargeable lamp can be stored and will continue to work for 15-20 hours without being plugged in;
- Fully charge the lamp the first time you use it. If not in use, recharge it within 3 months;
- Do not use the lamp while charging to avoid damaging the light;
- Do not use this lamp on high-temperature, flammable surfaces, or in humid environments to avoid damage or short circuits;
- For cleaning, use a soft cloth to dust the lamp. Avoid using cleaners that could damage the finish.

FRANÇAIS

Lampe de table à DEL avec interrupteur tactile à intensité variable.  
Usage intérieur seulement.

Instructions d'utilisation:  
Suivez les étapes 1 et 2.

- Cette lampe rechargeable peut être stockée et continuera de fonctionner pendant 15 à 20 heures sans être branchée;
- Chargez complètement la lampe lors de la première utilisation. Si elle n'est pas utilisée, rechargez-la dans un délai de 3 mois;
- N'utilisez pas la lampe pendant qu'elle charge afin d'éviter d'endommager la lumière;
- N'utilisez pas cette lampe sur des surfaces à haute température, inflammables ou dans des environnements humides pour éviter les dommages ou les courts-circuits;
- Utilisez un chiffon doux pour dépoussiérer la lampe. Évitez d'utiliser des nettoyants pouvant endommager la finition.


1

# RENWIL®

EST. 1967

1. Please use the power adapter correctly to charge the lamp (Voltage: 5V / Current: 1A/2A);  
The blue light will turn on while charging;  
The green light will turn on when fully charged.

Veillez utiliser correctement l'adaptateur secteur pour charger la lampe (Tension: 5V / Courant: 1A/2A);  
La lumière bleue s'allume pendant la charge;  
La lumière verte s'allume lorsque la charge est complète.



2